Panasonic

Operating Instructions
Air Conditioner



4-Way Cassette (Type U2)

Model No.

INDOOR UNIT

4-Way Cassette (Type U2)

S-36PU2E5B	S-71PU2E5B
S-45PU2E5B	S-100PU2E5B
S-50PU2E5B	S-125PU2E5B
S-60PU2E5B	S-140PU2E5B

OUTDOOR UNIT

Single Split

See the page 82.

ENGLISH 2 ~ 9
Before operating the unit, read these operating instructions thoroughly and keep them for future reference.

FRANÇAIS 10 ~ 17
Avant d'utiliser l'appareil, lisez ce mode d'emploi dans son intégralité et conservez-le pour toute référence ultérieure.

ESPAÑOL 18 ~ 25
Antes de operar la unidad, lea atentamente estas instrucciones de funcionamiento y guárdelas para futuras consultas.

DEUTSCH 26 ~ 33
Bevor Sie das Gerät in Betrieb nehmen, lesen Sie bitte diese Bedienungsanleitung aufmerksam durch und bewahren Sie sie für die künftige Verwendung auf.

ITALIANO 34 ~ 41
Prima di utilizzare l'unità, leggere a fondo queste istruzioni per l'uso e conservarle come riferimento futuro.

NEDERLANDS 42 ~ 49
Lees deze gebruiksinstructies goed door voor u het apparaat gebruikt en bewaar ze voor toekomstig gebruik.

PORTUGUÊS 50 ~ 57
Antes de utilizar o aparelho, leia completamente este manual de instruções e guarde-o para futuras referências.

ΕΛΛΗΝΙΚΆ 58 ~ 65
Πριν θέσετε τη μονάδα σε λειτουργία, διαβάστε πολύ καλά αυτές τις οδηγίες χρήσης και διατηρήστε τις για μελλοντική αναφορά.

БЪЛГАРСКИ 66 ~ 73
Преди да започнете експлоатация на този уред, прочетете внимателно тези инструкции и ги запазете, за да можете да правите справки с тях и в бъдеще.

TÜRKÇE 74 ~ 81
Üniteyi çalıştırmadan önce bu çalıştırma talimatlarını iyice okuyun ve gelecekte başvurmak için saklayın.

CE Panasonic Corporation
1006 Kadoma, Kadoma City, Osaka, Japan ACXF55-19091

Thank you for purchasing this Panasonic product.
This product is a commercial air conditioner indoor unit.
Installation Instructions attached.

Contents

- **Safety Precautions** 2
- **Precautions for Use** 5
- **Names of Parts** 6

- **Maintenance** 7
  - **• Operation Mechanism** 7
- **Troubleshooting** 8
  - **• Before Requesting Services** 9

- **Specifications** 83
  - **• Indoor unit** 83
  - **• Outdoor unit** 84
  - **• Corresponding language table** 87

WARNING	This symbol shows that this equipment uses a flammable refrigerant. If the refrigerant is leaked, together with an external ignition source, there is a possibility of ignition.
CAUTION	This symbol shows type of flammable refrigerant contained in the system.
CAUTION	This symbol shows that a service personnel should be handling this equipment with reference to the Technical Manual.
CAUTION	This symbol shows that there is information included in the Operating Instructions and/or Installation Instructions.

Product Information

If you have problems or questions concerning your Air Conditioner, you will need the following information. Model and serial numbers are on the nameplate.

Model No. _____

Serial No. _____

Date of purchase _____

Dealer's address _____

Phone number _____

Important Information Regarding The Refrigerant Used

NOTE

Refer to the Installation Instructions attached to the outdoor unit.

Safety Precautions

The following symbols used in this manual, alert you to potentially dangerous conditions to users, service personnel or the appliance:

⚠WARNING	This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.
⚠CAUTION	This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

Prohibited matters	Matters to be observed

- Read these Operating Instructions carefully before using this air conditioner. If you still have any difficulties or problems, consult your dealer for help.
- This air conditioner is designed to give you comfortable room conditions. Use this only for its intended purpose as described in these Operating Instructions.

⚠WARNING

Confirm to authorized dealer or specialist on usage of specified refrigerant type. Using of refrigerant other than the specified type may cause product damage, burst and injury etc.

This air conditioner has no ventilator for intaking fresh air from outdoors. You must open doors or windows frequently when you use gas or oil heating appliances in the same room, which consume a lot of oxygen from the air.
Otherwise there is a risk of suffocation in an extreme case.

Never use or store gasoline or other flammable vapor or liquid near the air conditioner — it is very dangerous.

Do not use this appliance in a potentially explosive atmosphere.

Never touch the unit with wet hands.

Do not insert your fingers or other objects into the air conditioner indoor or outdoor unit, rotating parts may cause injury.

⚠WARNING

If the refrigerant comes in contact with a flame, it produces a toxic gas.

For safety, be sure to turn the air conditioner off and also to disconnect the power before cleaning or servicing.

Pull off the power plug from a receptacle, or switch off the breaker, or switch off the power disconnecting mean to isolate the air conditioner from the main power supply in case of emergency.

Dispose of according to national and/or local legislation.

This product must not be modified or disassembled under any circumstances.
Modified or disassembled unit may cause fire, electric shock or injury.

Do not clean inside the indoor and outdoor units by users. Engage authorized dealer or specialist for cleaning.

In case of malfunction of this appliance, do not repair by yourself. Contact to the sales dealer or service dealer for a repair and disposal.

Provide a power outlet to be used exclusively for each unit, and a power supply disconnect, Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD) for overcurrent protection should be provided in the exclusive line.

Provide a power outlet exclusively for each unit, and full disconnection means having a contact separation in all poles must be incorporated in the fixed wiring in accordance with the wiring rules.

To prevent possible hazards from insulation failure, the unit must be grounded.

Do not use modified cord, joint cord, extension cord or unspecified cord to prevent overheating and fire.

The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).

Be aware that refrigerants may not contain an odour.

An unventilated area where the appliance using flammable refrigerants is installed shall be so constructed that should any refrigerant leak, it will not stagnate so as to create a fire or explosion hazard.

The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.

After the unit is installed, never fail to ask the installer for the floor space of the room where the unit is installed and the refrigerant charge amount.

In case the unit or the room divider is changed, never fail to consult the sales dealer or service dealer.

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

Do not pierce or burn.

In cases that require mechanical ventilation, ventilation openings shall be kept clear of obstruction.

⚠WARNING

The appliance shall be stored in a room without continuously operating open flames (for example: an operating gas appliance) and ignition sources (for example: an operating electric heater).

Stop using the product when any abnormality/failure occurs and disconnect the power plug or turn off the power switch and breaker. (Risk of smoke/fire/electric shock)

Examples of abnormality/failure:

- The ELCB trips frequently.
- The product sometimes does not start when turned on.
- The power is sometimes disconnected when the cord is moved.
- Burnt odor or abnormal noise is detected during operation.
- The body is deformed or abnormally hot.
- Water leaks from the indoor unit.
- Power cord or plug becomes abnormally hot.
- Fan speed cannot be controlled.
- The unit stops running immediately even if it is switched on for operation.
- The fan does not stop even if the operation is stopped.

Contact immediately your local dealer for maintenance/repair.

Do not sit or step on the unit. You may fall down accidentally.

⚠CAUTION

This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

<for European market only>
This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Keep the fire alarm and the air outlet at least 1.5m away from the unit.

Do not cool or heat the room too much if babies or invalids are present.

Do not turn the air conditioner on and off from the power mains switch. Use the ON/OFF operation button.

Do not stick anything into the air outlet of the outdoor unit. This is dangerous because the fan is rotating at high speed.

Do not touch the air inlet or the sharp aluminum fins of the outdoor unit. You may get injured.

Do not stick any object into the FAN CASE. You may be injured and the unit may be damaged.

NOTICE

- The appliance shall be stored so as to prevent mechanical damage from occurring.
- The compressor may occasionally stop during thunderstorms. This is not a mechanical failure. The unit automatically recovers after a few minutes.
- The English text is the original instructions. Other languages are translation of the original instructions.

Precautions for Use

Installation

- This air conditioner must be installed properly by qualified installation technicians in accordance with the Installation Instructions provided with the unit.
- Before installation, check that the voltage of the electric supply in your home or office is the same as the voltage shown on the nameplate.

⚠WARNING

Avoid the following locations for installation.

- Locations where smoke or combustible gas exists. Also locations of extremely high temperature such as a greenhouse.
- Locations where excessively high heat-generating objects are placed.

Attention:

- Avoid installing the outdoor unit where salty sea water can splash directly onto it or in sulphurous air near a spa. (To protect the air conditioner from heavy corrosion)

Wiring

- All wiring must conform to the local electrical codes. (Consult your dealer or a qualified electrician for details.)
- Each unit must be properly grounded with a ground (or earth) wire or through the supply wiring.
- Wiring must be done by a qualified electrician.

Operation Preparation

Turn the power mains on 5 hours before the start of operation.
(For warm-up)

- Leave the power mains ON for continuous use.

NOTE

Pull off the power plug from a receptacle, or switch off the breaker, or switch off the power disconnecting mean to isolate the air conditioner from the main power supply when not in use for a long time.

Tips for Energy Saving

■ Avoid

- **Do not block the air intake and outlet of the unit. (If either is obstructed, the unit will not function well, causing malfunction.)**
- During cooling operation, use sunshades, blinds or curtains to prevent direct sunlight from entering the room.

■ Do

- Always keep the air filter clean. (A clogged filter will impair the performance of the unit.) → “Maintenance” (P.7)
- To prevent conditioned air from escaping, keep windows, doors and any other openings closed.

Information for Users on Collection and Disposal of Old Equipment and Used Batteries

These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries should not be mixed with general household waste.
For proper treatment, recovery and recycling of old products and used batteries, please take them to applicable collection points, in accordance with your national legislation and the Directives 2002/96/EC and 2006/66/EC.
By disposing of these products and batteries correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling.
For more information about collection and recycling of old products and batteries, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.
Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.

For business users in the European Union
If you wish to discard electrical and electronic equipment, please contact your dealer or supplier for further information.

[Information on Disposal in other Countries outside the European Union]
These symbols are only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.

Note for the battery symbol (bottom two symbol examples):
This symbol might be used in combination with a chemical symbol. In this case it complies with the requirement set by the Directive for the chemical involved.

Names of Parts

INDOOR UNIT

Type U2



Label
(attached to the lid of electrical component box)

This air conditioner incorporates a biocidal product.
Ionized air generated by a device incorporated in the air conditioner deactivates bacteria and viruses in the air, and on surfaces, and inhibits mould growth on surfaces.
Active substances: free radicals generated in situ from ambient air or water

OUTDOOR UNIT

PE2 (Type 36, 50, 60)
PEY2 (Type 60, 71)

PE1 (Type 60, 71)
PEY1 (Type 100, 125)



PE1 (Type 100, 125, 140)
PEY1 (Type 140)



PE2 (Type 200, 250)



PZ2 (Type 60, 71)

PZ2 (Type 100, 125, 140)



Optional

Wireless Remote Controller

Model No.
CZ-RWSU3 (Type U2)

CZ-RWSC3
(For all indoor units)

Timer Remote Controller

Model No.
CZ-RTC4

For all indoor units

High-spec Wired Remote Controller

Model No.
CZ-RTC5A
CZ-RTC5B

For all indoor units

Read the Operating Instructions included with the Remote Controller.

■ Operation & Adjusting Airflow Direction

Refer to the Operating Instructions attached to the Remote Controller.

Maintenance

⚠WARNING

- For safety, be sure to turn the air conditioner off and disconnect the power before cleaning. (Otherwise, electric shock or injury may result because the fan is rotating at high speed.)
- Do not pour water on the indoor unit. (This may damage the internal components and cause an electric shock hazard.)

⚠CAUTION

- Never use solvents or harsh chemicals. Also, do not wipe plastic parts using very hot water. (This may cause deformation or change in colour.)
- Some metal edges and fins are sharp. Be careful when you clean those parts. (Injury may result.)
- Use a firm stool or ladder when cleaning an indoor unit installed in high locations.

Indoor unit (e.g. Type U2)



- The internal coil and other components of the outdoor unit must be cleaned periodically.
  • Consult your dealer or service center.

ENGLISH

■ Air Filter Maintenance

Consult your dealer or service center when the ▦ (Filter) appears on the display of the wired remote controller.

Timer Remote Controller

Filter indicator



High-spec Wired Remote Controller

Filter indicator



Operation Mechanism

■ Heating performance

- Since this air conditioner utilizes outside air for heating, its heating performance deteriorates as outside temperature decreases.
  (Due to heat pump system)
  →In that case, use another heating appliance.

■ Defrosting

- This appliance may start defrosting operation to melt frost formed in the outdoor unit.
  ①**Defrosting starts**: The indoor unit fan stops (or the speed becomes extremely slow).
  →"❋" (STANDBY) appears.
  ②**Heating operation resumes after several minutes**: The indoor unit fan remains stopped (or it will run at a very slow speed) until the indoor heat exchanger coil warms up sufficiently.
  → "❋" (STANDBY) is shown.
  ③**Defrosting is complete**: The indoor unit fan starts operation.
  → "❋" (STANDBY) disappears.

■ "DRY" operation

- Once the room temperature reaches the level that was set, the outdoor unit repeats the cycle of turning on and off automatically.
- When the outdoor unit is turned off, the indoor unit fan will stop, too.
  (To prevent the humidity in the room from rising again)
- When the room temperature is more likely to reach the level that was set, the fan speed is set to "breeze" (light wind) automatically.

■ Should the power failure occurs while the unit is running

When the unit automatically resumes operation after temporary power failure, it uses the same settings before the power was cut off.

Troubleshooting

Check before consulting or requesting services.

	Symptom		Cause / Action
Indoor unit	**Noise**	Sound like streaming water is heard during operation or after operation.	• Sound of refrigerant liquid flowing inside unit • Sound of drainage water through drain pipe
		Cracking noise is heard during operation or when operation stops.	• Sound due to temperature changes of parts
	Discharged air smells during operation.		• Indoor odor components, cigarette odor and cosmetic odor accumulated in the air conditioner and its air is discharged. • The unit inside is dirty. (Contact your dealer.)
	Dewdrops accumulate near the air outlet during cooling operation.		• Internal moisture is cooled by cool wind and accumulates as dewdrops.
	Fog occurs during cooling operation.		• If the air conditioner has been installed at places such as restaurants where large amounts of oil mist exist, cleaning is necessary because the unit inside (heat exchanger) is dirty. (Contact your dealer.)
	Fog occurs during heating operation.		• Defrost operation is in process.
	The fan is rotating for a while even though operation stops.		• Fan rotation makes operation smooth. • The fan may rotate to dry the heat exchanger depending on the setting.
	Airflow direction	Airflow direction changes while operating. Airflow direction cannot be set. Airflow direction cannot be changed.	• When air discharge temperature is low during heating operation, or during defrost operation, horizontal wind flow is made automatically. • The flap position may be set individually. (Type U2)
		The flap moves several times after the direction is changed.	• The flap moves to the standard position once, and then turns to the set airflow direction.
	Dust is discharged.		• Dust accumulated inside the indoor unit is discharged.
	At the initial high-speed operation, the fan sometimes rotates faster than the setting speed. (3 to 30 minutes)		• This is for operation check in order to confirm whether the fan motor rotation is within the range of use.
Outdoor unit	**No operation (When the power is turned on immediately / When operation is stopped and resumed immediately)**		• Operation is not activated for the first approx. 3 minutes because the compressor protection circuit is activated.
	Noise occurs during heating operation.		• Defrost operation is in process.
	Steam comes out during heating operation.		
	The fan continues to rotate even after the operation is stopped using the remote controller.		• This is for smooth operation.

Before Requesting Services

Symptom	Cause	Action
The air conditioner does not operate although the power is turned on.	Power failure or after power failure	Press the power ON/OFF button on the remote controller.
	The operation (power) button is turned off.	• If the breaker is turned off, turn the power on. • If the breaker has been tripped, consult your dealer without turning it on.
	Fuse blow out.	Contact your dealer.
Poor cooling or heating performance	The air intake or air outlet of indoor and outdoor units is clogged with dust.	Remove the dust.
	The fan speed switch is set to “Low”.*	Change to “Medium” or “High”.*
	Improper temperature settings	See “Tips for Energy Saving”. (P.5)
	The room is exposed to direct sunlight in cooling mode.	
	Doors or windows are open.	
	The air filter is clogged.	See “Maintenance”. (P.7)
	Too many heat sources in the room in cooling mode.	Use minimum heat sources and in a short time.
	Too many people in the room in cooling mode.	Lower the temperature setting or change to “Medium” or “High”.*

* Regarding the remote control display, see the page 83.

If your air conditioner does not work properly even after checking each item of “Before Requesting Services” and “Troubleshooting”

- Stop the operation immediately and turn the power off. Then contact your dealer and report the serial number and symptom. You also report if the inspection mark ⚠ and the letters E, F, H, L, P in combination with numbers appear on the LCD of the remote controller.
- Never repair the air conditioner by yourself since it is very dangerous for you to do so.

Connectable outdoor unit lineup

Europe

■ **Refrigerant type : R410A**

Outdoor unit type		36	45	50	60
PE1,PE2	1-phase	U-36PE2E5A		U-50PE2E5A	U-60PE2E5A
	3-phase				
PEY1,PEY2	1-phase				U-60PEY2E5
	3-phase				

Outdoor unit type		71	100	125	140
PE1,PE2	1-phase	U-71PE1E5A	U-100PE1E5A	U-125PE1E5A	U-140PE1E5A
	3-phase	U-71PE1E8A	U-100PE1E8A	U-125PE1E8A	U-140PE1E8A
PEY1,PEY2	1-phase	U-71PEY2E5	U-100PEY1E5	U-125PEY1E5	
	3-phase		U-100PEY1E8	U-125PEY1E8	U-140PEY1E8

Outdoor unit type		200	250		
PE2	3-phase	U-200PE2E8A	U-250PE2E8A		

■ **Refrigerant type : R32**

Outdoor unit type		71	100	125	140
PZ2	1-phase		U-100PZ2E5	U-125PZ2E5	U-140PZ2E5
	3-phase		U-100PZ2E8	U-125PZ2E8	U-140PZ2E8

Oceania

■ **Refrigerant type : R410A**

Outdoor unit type		36	45	50	60
PE1	1-phase				U-60PE1R5A
	3-phase				

Outdoor unit type		71	100	125	140
PE1	1-phase	U-71PE1R5A	U-100PE1R5A	U-125PE1R5A	U-140PE1R5A
	3-phase		U-100PE1R8A	U-125PE1R8A	U-140PE1R8A

■ **Refrigerant type : R32**

Outdoor unit type		36	45	50	60
PZ2	1-phase				U-60PZ2R5
	3-phase				

Outdoor unit type		71	100	125	140
PZ2	1-phase	U-71PZ2R5	U-100PZ2R5	U-125PZ2R5	U-140PZ2R5
	3-phase		U-100PZ2R8	U-125PZ2R8	U-140PZ2R8

Specifications

Indoor unit

4-Way Cassette (Type U2)

Model Name			S-36PU2E5B	S-45PU2E5B	S-50PU2E5B	S-60PU2E5B	S-71PU2E5B	S-100PU2E5B	S-125PU2E5B	S-140PU2E5B
Power source (Europe)			220 - 230 - 240 V ～ 50 Hz							
Power source (Oceania)			–			230 - 240 V ～ 50 Hz				
Cooling capacity		kW	3.6	4.5	5.0	6.0	7.1	10.0	12.5	14.0
		BTU/h	12,300	15,400	17,100	20,500	24,200	34,100	42,700	47,800
	Sensible	kW	3.2	3.7	4.0	4.9	5.5	8.3	9.5	10.2
	Latent	kW	0.4	0.8	1.0	1.1	1.6	1.7	3.0	3.8
Heating capacity		kW	4.2	5.2	5.6	7.0	8.0	11.2	14.0	16.0
		BTU/h	14,300	17,700	19,100	23,900	27,300	38,200	47,800	54,600
Cooling electric power input		kW	0.024	0.026	0.029	0.038	0.042	0.100	0.110	0.120
Heating electric power input		kW	0.022	0.024	0.027	0.036	0.040	0.095	0.105	0.115
Sound pressure level**	High	dB(A)	30	31	32	36	37	45	46	47
	Medium	dB(A)	28	28	29	31	31	38	39	40
	Low	dB(A)	27	27	27	28	28	32	33	34
Sound power level**	High	dB(A)	45	46	47	51	52	60	61	62
	Medium	dB(A)	43	43	44	46	46	53	54	55
	Low	dB(A)	42	42	42	43	43	47	48	49
Unit dimensions (H×W×D) *		mm	289.5×950×950	289.5×950×950	289.5×950×950	289.5×950×950	289.5×950×950	352.5×950×950	352.5×950×950	352.5×950×950
Net weight *		kg	24	24	24	25	25	30	30	30

Operation condition temperature range
• Cooling mode : 14°C~25°C WB / 18°C~32°C DB • Heating mode : 16°C~30°C DB

* Values include the dimension and weight of an optional ceiling panel.
** Fan speed display on the remote controller

High : (CZ-RTC4), (CZ-RTC5A, CZ-RTC5B)

Medium : (CZ-RTC4),  (CZ-RTC5A, CZ-RTC5B)

Low : (CZ-RTC4),  (CZ-RTC5A, CZ-RTC5B)

Specifications

Outdoor unit

Single Split Outdoor Unit (R410A)

Europe	**Model Name**		U-36PE2E5A	U-50PE2E5A	U-60PE2E5A
	Power source		220 - 230 - 240 V ～ 50 Hz		
Cooling capacity		kW	3.6	5.0	6.0
		BTU/h	12,300	17,100	20,500
Heating capacity		kW	4.0	5.6	7.0
		BTU/h	13,600	19,100	23,900
Sound Pressure level (Cooling / Heating)		dB(A)	45 / 46	46 / 48	46 / 49
Sound Power level (Cooling / Heating)		dB(A)	64 / 66	65 / 68	65 / 69
Unit Dimensions (H×W×D)		mm	619×799×299	619×799×299	619×799×299
Net weight		kg	39	39	40

Operation condition temperature range
• Cooling mode : -15°C~46°C DB • Heating mode : -20°C~18°C WB / -20°C~24°C DB

Europe	**Model Name**		–	U-71PE1E5A	U-100PE1E5A	U-125PE1E5A	U-140PE1E5A
	Power source		220 - 230 - 240 V ～ 50 Hz				
Oceania	**Model Name**		U-60PE1R5A	U-71PE1R5A	U-100PE1R5A	U-125PE1R5A	U-140PE1R5A
	Power source		230 - 240 V ～ 50 Hz				
Cooling capacity		kW	6.0	7.1	10.0	12.5	14.0
		BTU/h	20,500	24,200	34,100	42,700	47,800
Heating capacity		kW	7.0	8.0	11.2	14.0	16.0
		BTU/h	23,900	27,300	38,200	47,800	54,600
Sound Pressure level (Cooling / Heating)		dB(A)	48 / 50	48 / 50	52 / 52	53 / 53	54 / 55
Sound Power level (Cooling / Heating)		dB(A)	65 / 67	65 / 67	69 / 69	70 / 70	71 / 71
Unit Dimensions (H×W×D)		mm	996×940×340	996×940×340	1,416×940×340	1,416×940×340	1,416×940×340
Net weight		kg	68	69	98	98	98

Operation condition temperature range
• Cooling mode : -15°C~46°C DB • Heating mode : -20°C~18°C WB / -20°C~24°C DB

Rated conditions
Cooling : Indoor intake air temp. 27°C DB / 19°C WB. Outdoor intake air temp. 35°C DB.
Heating : Indoor intake air temp. 20°C DB. Outdoor intake air temp. 7°C DB / 6°C WB.

Europe	Model Name		U-71PE1E8A	U-100PE1E8A	U-125PE1E8A	U-140PE1E8A	U-200PE2E8A	U-250PE2E8A
	Power source		380 - 400 - 415 V 3N ~ 50 Hz					
Oceania	Model Name		–	U-100PE1R8A	U-125PE1R8A	U-140PE1R8A	–	–
	Power source		400 - 415 V 3N ~ 50 Hz					
Cooling capacity		kW	7.1	10.0	12.5	14.0	20.0	25.0
		BTU/h	24,200	34,100	42,700	47,800	68,200	85,300
Heating capacity		kW	8.0	11.2	14.0	16.0	22.4	28.0
		BTU/h	27,300	38,200	47,800	54,600	76,400	95,500
Sound Pressure level (Cooling / Heating)		dB(A)	48 / 50	52 / 52	53 / 53	54 / 55	60 / 62	61 / 63
Sound Power level (Cooling / Heating)		dB(A)	65 / 67	69 / 69	70 / 70	71 / 71	78 / 80	80 / 82
Unit Dimensions (H×W×D)		mm	996×940×340	1,416×940×340	1,416×940×340	1,416×940×340	1,500×980×370	1,500×980×370
Net weight		kg	71	98	98	98	127	138

Operation condition temperature range
• Cooling mode : -15°C~46°C DB • Heating mode : -20°C~18°C WB / -20°C~24°C DB

Europe	Model Name		U-60PEY2E5	U-71PEY2E5	U-100PEY1E5	U-125PEY1E5
	Power source		220 - 230 - 240 V ~ 50 Hz			
Cooling capacity		kW	6.0	7.1	10.0	12.5
		BTU/h	20,500	24,200	34,100	42,700
Heating capacity		kW	6.0	7.1	10.0	12.5
		BTU/h	20,500	24,200	34,100	42,700
Sound Pressure level (Cooling / Heating)		dB(A)	46 / 48	49 / 49	54 / 54	56 / 56
Sound Power level (Cooling / Heating)		dB(A)	65 / 68	69 / 69	70 / 70	73 / 73
Unit Dimensions (H×W×D)		mm	619×799×299	619×799×299	996×940×340	996×940×340
Net weight		kg	40	40	73	85

Operation condition temperature range
• Cooling mode : -10°C~43°C DB • Heating mode : -15°C~18°C WB / -15°C~24°C DB

Europe	Model Name		U-100PEY1E8	U-125PEY1E8	U-140PEY1E8
	Power source		380 - 400 - 415 V 3N ~ 50 Hz		
Cooling capacity		kW	10.0	12.5	14.0
		BTU/h	34,100	42,700	47,800
Heating capacity		kW	10.0	12.5	14.0
		BTU/h	34,100	42,700	47,800
Sound Pressure level (Cooling / Heating)		dB(A)	54 / 54	56 / 56	54 / 53
Sound Power level (Cooling / Heating)		dB(A)	70 / 70	73 / 73	71 / 70
Unit Dimensions (H×W×D)		mm	996×940×340	996×940×340	1,416×940×340
Net weight		kg	73	85	98

Operation condition temperature range
• Cooling mode : -10°C~43°C DB • Heating mode : -15°C~18°C WB / -15°C~24°C DB

Rated conditions
Cooling : Indoor intake air temp. 27°C DB / 19°C WB. Outdoor intake air temp. 35°C DB.
Heating : Indoor intake air temp. 20°C DB. Outdoor intake air temp. 7°C DB / 6°C WB.

Specifications

Outdoor unit

Single Split Outdoor Unit (R32)

Europe	**Model Name**		–	–	U-100PZ2E5	U-125PZ2E5	U-140PZ2E5
	Power source		220 - 230 - 240 V ~ 50 Hz				
Oceania	**Model Name**		U-60PZ2R5	U-71PZ2R5	U-100PZ2R5	U-125PZ2R5	U-140PZ2R5
	Power source		230 - 240 V ～ 50 Hz				
Cooling capacity		kW	6.0	7.1	Refer to the Operating Instructions supplied with the outdoor unit.		
		BTU/h	20,500	24,200			
Heating capacity		kW	6.0	7.1			
		BTU/h	20,500	24,200			
Sound Pressure level (Cooling / Heating)		dB(A)	46 / 48	49 / 49			
Sound Power level (Cooling / Heating)		dB(A)	65 / 66	67 / 67			
Unit Dimensions (H×W×D)		mm	695×875×320	695×875×320			
Net weight		kg	44	44			

Operation condition temperature range
• Cooling mode : -10°C ~43°C DB • Heating mode : -15°C~18°C WB / -15°C~24°C DB

Europe	**Model Name**		U-100PZ2E8	U-125PZ2E8	U-140PZ2E8
	Power source		380 - 400 - 415 V 3N ～ 50 Hz		
Oceania	**Model Name**		U-100PZ2R8	U-125PZ2R8	U-140PZ2R8
	Power source		400 - 415 V 3N ～ 50 Hz		
Cooling capacity		kW	Refer to the Operating Instructions supplied with the outdoor unit.		
		BTU/h			
Heating capacity		kW			
		BTU/h			
Sound Pressure level (Cooling / Heating)		dB(A)			
Sound Power level (Cooling / Heating)		dB(A)			
Unit Dimensions (H×W×D)		mm			
Net weight		kg			

Operation condition temperature range
• Cooling mode : -10°C~43°C DB • Heating mode : -15°C~18°C WB / -15°C~24°C DB

Rated conditions
Cooling : Indoor intake air temp. 27°C DB / 19°C WB. Outdoor intake air temp. 35°C DB.
Heating : Indoor intake air temp. 20°C DB. Outdoor intake air temp. 7°C DB / 6°C WB.

Corresponding language table

English	Français	Español	Deutsch
4-Way Cassette (Type U2)	Cassette 4 voies (Type U2)	Cassette de 4 vías (Tipo U2)	4-Weg-Kassette (Typ U2)
Single Split	Bi-bloc simple	Un solo split	Einzel-Split

English	Italiano	Nederlands	Português
4-Way Cassette (Type U2)	A cassetta a 4 vie (Tipo U2)	4-Weg cassette (Type U2)	Cassete de 4 vias (Tipo U2)
Single Split	Split singolo	Enkele splitsing	Single split

English	Ελληνικη	Български	Türkçe
4-Way Cassette (Type U2)	4δρομη κασέτα (Τύπος U2)	4-пътен касетен (Тип U2)	4 Yöne Üflemeli Kaset (U2 tipi)
Single Split	Απλου συστηματοσ	Единичен сплит	Tekli Split

English	Français	Español	Deutsch
Model Name	Nom du modèle	Nombre del modelo	Modellbezeichnung
Power Source	Source d'alimentation	Fuente de alimentación	Spannungsquelle
Cooling Capacity	Capacité de refroidissement	Capacidad de refrigeración	Kühlleistung
Sensible	Sensible	Sensible	Sensibel
Latent	Latent	Latente	Latent
Heating Capacity	Capacité de chauffage	Capacidad de calefacción	Heizleistung
Cooling electric power input	Puissance électrique absorbée de refroidissement	Entrada de potencia eléctrica durante refrigeración	Elektrische Leistungsaufnahme Kühlen
Heating electric power input	Puissance électrique absorbée de chauffage	Entrada de potencia eléctrica durante calefacción	Elektrische Leistungsaufnahme Heizen
Sound Pressure Level (High/Medium/Low)	Niveau de pression sonore (Haut/Moyen/Bas)	Nivel de presión acústica (alto/medio/bajo)	Schalldruckpegel (hoch/mittel/niedrig)
Sound Power Level (High/Medium/Low)	Niveau de puissance sonore (Haut/Moyen/Bas)	Nivel de potencia acústica (alto/medio/bajo)	Schallleistungspegel (hoch/mittel/niedrig)
Unit Dimensions (H×W×D; mm)	Dimensions d'unité (H×L×P ; mm)	Dimensiones de la unidad (Alto × Largo × Ancho; mm)	Geräteabmessungen (H × B × T [mm])
(H×W×D: ceiling dimension)	(H×L×P : dimensions plafond)	(Alto × Largo × Ancho: dimensión del techo)	(H × B × T: Deckenmaß)
Net Weight (kg)	Poids net (kg)	Peso neto (kg)	Nettogewicht (kg)

Specifications

Corresponding language table

English	Italiano	Nederlands	Português
Model Name	Modello	Modelnaam	Nome do modelo
Power Source	Fonte di alimentazione	Voeding	Fonte de alimentação
Cooling Capacity	Capacità di raffreddamento	Koelingscapaciteit	Capacidade de arrefecimento
Sensible	Sensibile	Verstandig	Sensível
Latent	Latente	Latent	Latente
Heating Capacity	Capacità di riscaldamento	Verwarmingscapaciteit	Capacidade de aquecimento
Cooling electric power input	Ingresso di alimentazione elettrica di raffreddamento	Elektrisch ingangsvermogen bij koelen	Entrada de energia eléctrica de arrefecimento
Heating electric power input	Ingresso di alimentazione elettrica di riscaldamento	Elektrisch ingangsvermogen bij verwarmen	Entrada de energia eléctrica de aquecimento
Sound Pressure Level (High/Medium/Low)	Livello di pressione acustica (alto/medio/basso)	Geluidsdrukniveau (hoog/normaal/laag)	Nível da pressão do som (Alto/Médio/Baixo)
Sound Power Level (High/Medium/Low)	Livello di potenza acustica (alto/medio/basso)	Geluidsvermogenniveau (hoog/normaal/laag)	Nível da potência de som (Alto/Médio/Baixo)
Unit Dimensions (H×W×D; mm)	Dimensioni unità (A×L×P; mm)	Afmetingen van de unit (H × B × D; mm)	Dimensões da unidade (A×L×P; mm)
(H×W×D: ceiling dimension)	(A×L×P: dimensione soffitto)	(H × B × D: plafondafmeting)	(A×L×P: dimensão do tecto)
Net Weight (kg)	Peso netto (kg)	Nettogewicht (kg)	Peso líquido (kg)

English	Ελληνικη	Български	Türkçe
Model Name	Όνομα μοντέλου	Наименование на модел	Model Adı
Power Source	Πηγή ισχύος	Захранване	Güç Kaynağı
Cooling Capacity	Δυνατότητα ψύξης	Охлаждаща мощност	Soğutma Kapasitesi
Sensible	Αισθητή	Значително	Duyulur
Latent	Λανθάνουσα	Латентно	Gizli
Heating Capacity	Δυνατότητα θέρμανσης	Отоплителна мощност	Isıtma Kapasitesi
Cooling electric power input	Είσοδος ηλεκτρικής ισχύος για ψύξη	Охлаждане входяща електроенергия	Soğutma sırasında çekilen elektrik gücü
Heating electric power input	Είσοδος ηλεκτρικής ισχύος για θέρμανση	Отопление входяща електроенергия	Isıtma sırasında çekilen elektrik gücü
Sound Pressure Level (High/Medium/Low)	Επίπεδο πίεσης ήχου (Υψηλό/Μεσαίο/Χαμηλό)	Ниво на звуково налягане (Високо/Средно/Ниско)	Ses Basınç Düzeyi (Yüksek/Orta/Düşük)
Sound Power Level (High/Medium/Low)	Επίπεδο ισχύος ήχου (Υψηλό/Μεσαίο/Χαμηλό)	Ниво на сила на звука (Високо/Средно/Ниско)	Ses Güç Düzeyi (Yüksek/Orta/Düşük)
Unit Dimensions (H×W×D; mm)	Διαστάσεις μονάδας (Υ×Π×Β, mm)	Размери на модула (В×Ш×Д, мм)	Ünite Boyutları (Y×G×D; mm)
(H×W×D: ceiling dimension)	(Υ×Π×Β: διαστάσεις οροφής)	(В×Ш×Д: размери на тавана)	(Y×G×D: tavan boyutu)
Net Weight (kg)	Καθαρό βάρος (kg)	Нетно тегло (кг)	Net Ağırlık (kg)

English	Values include the dimension and weight of an optional ceiling panel.
Français	Les valeurs comprennent les dimensions et le poids d'un plafonnier en option.
Español	Los valores incluyen las dimensiones y el peso de un panel de techo opcional.
Deutsch	Die Werte schließen Abmessungen und Gewicht einer als Sonderausstattung erhältlichen Deckenverkleidung mit ein.
Italiano	I valori includono le dimensioni e il peso di un pannello del soffitto opzionale.
Nederlands	Waarden inclusief afmetingen en gewicht van optioneel plafondpaneel.
Português	Os valores incluem as dimensões e o peso de um painel de tecto opcional.
Ελληνικη	Οι τιμές περιλαμβάνουν τη διάσταση και το βάρος ενός προαιρετικού πάνελ οροφής.
Български	Стойностите включват размери и тегло на опционен панел за облицовка.
Türkçe	Değerlere bir opsiyonel tavan panelinin boyutu ve ağırlığı da dahildir.

English	Fan speed display on the remote controller
Français	La vitesse du ventilateur est affichée sur la télécommande
Español	En el mando a distancia se mostrará la velocidad del ventilador
Deutsch	Gebläseanzeige an der Fernbedienung
Italiano	Visualizzazione della velocità della ventola sul telecomando
Nederlands	De ventilatorsnelheid zoals getoond op de afstandsbediening
Português	Visualização da velocidade do ventilador no telecomando
Ελληνικη	Ένδειξη ταχύτητας ανεμιστήρα στο τηλεχειριστήριο
Български	На екрана на дистанционното управление се изписва скоростта на вентилатора
Türkçe	Uzaktan kumandadaki fan devri ekranı

English	Refer to the Operating Instructions supplied with the outdoor unit.
Français	Consultez le Mode d'emploi qui accompagne l'unité extérieure.
Español	Consulte las Instrucciones de funcionamiento suministradas con la unidad exterior.
Deutsch	Siehe mit der Außeneinheit gelieferte Bedienungsanleitung.
Italiano	Vedere le Istruzioni per l'uso fornite con l'unità esterna.
Nederlands	Raadpleeg de handleiding die wordt meegeleverd met de buitenunit.
Português	Consulte as instruções de instalação fornecidas com a unidade exterior.
Ελληνικη	Ανατρέξτε στις Οδηγίες λειτουργίας που παρέχονται με την εξωτερική μονάδα.
Български	Вижте инструкциите за експлоатация, предоставени с външния модул.
Türkçe	Dış üniteyle birlikte verilen Çalıştırma Talimatlarına bakın.

MEMO

MEMO

Panasonic Corporation
Website: http://www.panasonic.com

© Panasonic Corporation 2017 - 2018

Printed in Malaysia

Authorised representative in EU
Panasonic Testing Centre
Panasonic Marketing Europe GmbH
Winsbergring 15, 22525 Hamburg, Germany

ACXF55-19091
DC1117-10218